



NOTES:

- 1) SECURE ANCHORS AT BOTH ENDS INTO WALL. TIGHTEN CABLE USING TURNBUCKLES. ON EXTREME LONG RUNS OF CABLE, INTERMEDIATE VERTICAL CABLE SUPPORT MAY BE REQUIRED.
- 2) TIE-WIRE TO BE CINCHED UP TIGHT TO CABLE SO TO PREVENT SLIPPAGE.

